

## PU Injection Resins

# WEBAC® PURseal M ACC3

- ▶ Foam additive for **WEBAC® PURseal**. It turns the solid PU resin into a rigid foam

### Range of application

- Accelerates foam formation of PU resins **WEBAC® PURseal**, **WEBAC® PURseal M**, **WEBAC® PURseal M S**, **WEBAC® PURseal M SL5** and **WEBAC® PURseal M SL10**

### Application instruction

- Shake well before use
- Add accelerator amount referring to total volume (component A + B)
- Mix into component A immediately before use


WEBAC-Chemie GmbH  
 Fahrenberg 22  
 22885 Barsbüttel  
 Germany  
 Tel. +49 40 67057-0  
 Fax +49 40 6703227  
 info@webac.de  
 www.webac-grouts.com

[www.webac.de](http://www.webac.de)

### Reaction time

of **WEBAC® PURseal M** depending on amount of **WEBAC® PURseal M ACC3** added at 5 °C/41 °F, 10 °C/50 °F and 23 °C/73 °F

- Start of reaction
- End of Reaction
- II Fault tolerance



## Technische Information Technical Information


## PU Injection Resins

# WEBAC® PURseal M ACC3

### Reaction time

of WEBAC® PURseal M S depending on amount of WEBAC® PURseal M ACC3 added

- Start of reaction
- End of Reaction
- II Fault tolerance



Further reaction times on request.

WEBAC-Chemie GmbH  
 Fahrenberg 22  
 22885 Barsbüttel  
 Germany  
 Tel. +49 40 67057-0  
 Fax +49 40 6703227  
 info@webac.de  
 www.webac-grouts.com

[www.webac.de](http://www.webac.de)